

- 0) Before Searching MI-12B, the Concrete Shielding Blocks will need to be checked.
- 1) "A" and "B" enter the MI-12B enclosure via MI-12 Service Building.
- 2) "A" and "B" proceed to Interlock box #1.

Interlock #1

- 3) "A" and "B" sweep the enclosure towards the target area.
- 4) "A" waits by the exit while while "B" uses the ladder to check on top of things, the Horn area and the Raw system.
- 5) "A" and "B" exit and reset Interlock Box #2.